

GUI

- Report problems and error messages to CODESYS
- How to open an Example Project
- Coloring the background of the search function, color for the marking of the search results
- Expired certificates message for encrypted communication
- Switch off the precompilation
- What are the meanings of the memory occupation data in the message window?
- CODESYS communication: Limited data size between PLC and CODESYS IDE